



# High Productivity, Authentic Quality

HIGH-SPEED  
PRODUCTIVITY

HIGH-DEFINITION  
OUTPUT

ULTIMATE  
VERSATILITY



High speed with the fastest  
flatbed UV printer in its class

- ▶ Staggered print heads, powerful lamps and increased bed size make the MO-240 the ultimate in high-production flatbed UV print.
- ▶ Deliver printing speeds up to approximately 1.4 times faster than comparable models from other brands.
- ▶ Twice as fast as previous models when printing white or gloss ink.



Unrivalled print quality with a  
complete solution

- ▶ Specially formulated UV inks deliver high-definition results every time.
- ▶ Reproduce small letters, fine textures, gradations and high-quality graphics with ease.
- ▶ Additional Red and Orange inks extend the color gamut ensuring accurate color matching.



Versatile and flexible to  
address any business need

- ▶ Print on a wide variety of substrates and objects with the same powerful ink formulation.
- ▶ Distance Mode makes it possible to print high quality graphics on curved or uneven surfaces.
- ▶ An optional rotary printing unit allows customisation of cylindrical objects.

## Additional Features

- + Included VersaWorks 6 RIP—featuring new True Rich Color 3 preset, Nearest Color Finder, and Variable Data Printing function.
- + A variety of available ink configurations expand your capabilities to include rich colors and interesting spot UV effects.
- + Roland DG Connect App ready—giving you instant access to important data about print jobs as well as your business.
- + A user-friendly 7” touch screen displays all relevant information making print set-up intuitive and fast.

## Technical Specifications

### MO-240

Dimension		1,601 mm × 1,267 mm × 760 mm (63.1 in. × 49.9 in. × 30.0 in.)
Attachable objects to be printed on	Width	Max. 640 mm (25.1 in.)
	Length	Max. 488 mm (19.2 in.)
	Thickness	Max. 204 mm (8 in.)
	Weight	Max. 8 kg (17.6 lb.) (When using a vacuum table: max. 4 kg [8.8 lb.])
Printing width/printing length (width x length)		Max. 610 mm × 458 mm (24 in. × 18 in.)
Ink	Inks	Eight Colors (Cyan, Magenta, Yellow, Black, Orange, Red, White, Gloss) and, Primer
	Type	ECO-UV (EUV5P) 750 ml pouch
	Configurations	CMYKGIWhReOr CMYKWhReOrPr CMYKGIWhRePr CMYKWhWhReOr CMYKGIWhWhPr CMYKGIWhWh CMYK
Control panel		7 in. touchscreen display
Resolution		Max. 1,200 dpi
RIP (included)		VersaWorks

Roland DG reserves the right to make changes in specifications, materials or accessories without notice. Actual output may vary. For optimum output quality, periodic maintenance to critical components may be required. Please contact your Roland DG dealer for details. No guarantee or warranty is implied other than expressly stated. Roland DG shall not be liable for any incidental or consequential damages, whether foreseeable or not, caused by defects in such products. Reproduction or use of copyrighted material is governed by local, national, and international laws. Customers are responsible for observing all applicable laws and are liable for any infringement. Roland DG Corporation has licensed the MMP technology from the TPL Group.