



NEW

UV-LED Flatbed Printer with Outstanding Price-Performance



Included





High Productivity up to 27.6m²/h

9

4'x8' boards an hour

CMYK 720 × 600 dpi 4

4'x8' boards an hour

CMYKWh 720 × 600 dpi

Print Directly onto a Variety of Materials

- Acrylic
- Wood
- PVC
- PETG
- PC
- Foam
- Aluminum composite plate

Higher Quality Output

Variable Dot Printing Technology

Uses different sizes of ink droplets with high precision.

True Rich Color

Combines both "vividness" and "naturalness" in a single print job.

High Level of Safety

Safe Design

Equipped with a safety sensor for additional operator protection plus four emergency stop switches.



Low VOCs makes inks safe to use indoors.

Applications







Specifications Specification Specificatio		
Printing method		Piezo ink-jet method
Acceptable media	Width	Max. 2,440 mm (96 in.)
	Length	Max. 1,220 mm (48 in.)
	Thickness	Max. 95 mm (3.74 in.)
	Weight	Max. 45 kg/m² (99 lb./m²)
Maximum printing width/printing length *		Max. 2,440 x 1,120 mm (96 x 44 in.)
lnk	Туре	E-US ink
	Colors	Six colors (cyan, magenta, yellow, black, white, gloss) Four colors (cyan, magenta, yellow, black)
	Tank capacity	2.5 L
Ink-curing unit		Built-in UV-LED lamp
Printing resolution (dots per inch)		Max. 720 x 1200 dpi
Connectivity		Ethernet 1000BASE-T for control PC only
Power requirements		AC 220 V, 50/60 Hz, 32 A
Acoustic noise level	During operation	80 dB (A) or less
Dimensions		Width x Depth x Height: 4,556 x 2,100 x 1,470 mm (180 x 83 x 58 in.)
Weight		1,300 kg (2,870 lb.)
Environment	During operation	Temperature: 18 to 25 °C (64.4 to 77 °F), humidity: 40 to 70 %RH (no condensation)
Included items		Power cord, user's manual (to download), Software RIP (to download), Goggles, etc.

^{*} The maximum printing area can be extended up to 2,440 \times 1,220 mm (96 \times 48 in.).

Accessories		
Model	Description	
E-US-CY10	UV Ink 1,000 ml, Cyan	
E-US-MG10	UV Ink 1,000 ml, Magenta	
E-US-YE10	UV Ink 1,000 ml, Yellow	
E-US-BK10	UV Ink 1,000 ml, Black	
E-US-WH10	UV Ink 1000 ml, White	
E-US-GL10	UV Ink 1,000 ml, Gloss	
E-US-CL10	Cleaning liquid, 1,000 ml	





AUTHORISED DEALER: March, 2022